

## Planar Combination Antenna K60ZVD

GSM 850/900/1800/1900 MHz + UMTS + GPS low current

Desk Mount



- **No changes and modifications on the body**
- **Mounting by adhesive bonding possible on non-metallic surfaces (adhesive bonding antenna)**
- **Including 868 MHz – services and DECT**
- **Our products are RoHS- and REACH-conform**



## Technical Data

### GSM

Frequency Range	850/900/1800/1900 + 2100 MHz
VSWR*	< 2.0 typ.
Peak Gain*	+2 dBi typ. (900 MHz) +3 dBi typ. (1800 MHz) +1 dBi typ. (2100 MHz)
Power max.	10 W
Diagnostic resistor	10 kΩ (others on request)



### GPS

Frequency	1575.42 MHz
VSWR	1.5 typ.
Peak Gain	18 dBi typ.
Power Supply	3V ±10%; 4mA typ.
V <sub>DD</sub> max.	4.0V
Input Power max.	+10dBm
Current max.	4.5mA


\* Measured with 0.6m cable on 30x30cm ground plane

## Mechanical Data



Dimensions (ØxH)	ca. 68 mm x 12 mm
Temperature Range	-40°C to +85°C (operating temperature)
Connection (Standard)	ca. 3m connecting cable RG174 with GSM/FME(f); GPS/SMA(m) Other cablelengths and connectors see ordering example and connector list in Internet




**Radiation diagram (typ.)\***



**GSM 900 MHz**  
Peak Gain: +2 dBi



**GSM 1800 MHz**  
Peak Gain: +3 dBi



**GSM 2100 MHz**  
Peak Gain: +1 dBi

\* Measured with 0.6m cable on 30x30cm ground plane

## Accreditation

<input type="checkbox"/>	E-Code	<b>e 13</b> 02 1510	high gain (A)
<input type="checkbox"/>	E-Code	<b>e 13</b> 02 1509	low gain (L)
<input checked="" type="checkbox"/>	E-Code	<b>e 13</b> 03 6371	low current (V)


## Mounting Instructions

- To avoid mechanical stress the antenna should not be attached on doors or flaps.
- No extra ground planes are necessary for this antenna (ground plane inside).
- Mountable on all clean, smooth and stainless surfaces.
- Don't stick the antenna under +10°C to get an optimal adhesion of the sticker.
- Clean seating nonfat before sticking by using the delivered cleaning cloth
- First remove protection foil on one side of the sticker and stick it on the seating, avoid formation of bubbles.
- Now the other protection foil has to be removed from the sticker. Stick the antenna on with it's level side and advantage direction (cable pointing below) and apply sufficient pressure.

**Delivery includes:** Sticker; cleaning cloth with isopropanol

**Important:** Before sticking please test the adhesive bonding possibility of the material!

## Ordering example



## Warranty

The lawful warranty conditions apply.